

ONDOT: Programming Barcodes for LI4278

Configuration name in Utility :

Last Modified :

Windows Filename :

Plug-in Name : _ONDOT

09-Dez-25

Config File_LI4278_Untitled1_2025.12.09.scncfg



LI4278-STANDARD SR MODELS-018_



Instructions: Scan barcodes in order, starting with programming barcode 1.

1/8. Enable Parameter Scanning



2/8. Set Factory Defaults



Put into Cradle

Cable Connection Settings

USB

3/8. USB Device Type Default (HID Keyboard Emulation),USB Country Code Windows German



Put into Cradle

4/8. Emulate Keypad Enable



Modify Data

5/8. Prefix: CTRL J/GROUP SEPERATOR,1,0,2,9,Suffix 1 Enter,7,0,1,3



6/8. Suffix 2 Enter,7,0,1,3,Scan Data Transmission Format <Prefix><Data><Suffix 1>



ONDOT: Programming Barcodes for LI4278

Configuration name in Utility :

Last Modified :

Windows Filename :

Plug-in Name : _ONDOT

09-Dez-25

Config File_LI4278_Untitled1_2025.12.09.scncfg



LI4278-STANDARD SR MODELS-018_



General Parameter Settings

7/8. Transmit Code Id AIM Code ID



8/8. Configuration File ONDOT



Put into Cradle